

Sea World Manual

Tel: (TAIWAN) : +886-2-2255-2636

Fax (TAIWAN) : +886-2-2255-6366

Tel: (CHINA) : +8620-84851613

Fax (CHINA) : +8620-84559322

www.tecway.com.tw

www.mecpower.com.cn

SETTING:

TIME SETTING SHEET:

Sub dial switch 1	Sub dial switch 2	Sub dial switch 3	set time for
OFF	OFF	OFF	1.5 mins (Factory setting)
ON	OFF	OFF	1 min
OFF	ON	OFF	2 mins
ON	ON	OFF	3 mins
OFF	OFF	ON	4 mins
ON	OFF	ON	5 mins
OFF	ON	ON	6 mins
ON	ON	ON	7 mins


Coins setting sheet:

Sub dial switch 4	Sub dial switch 5	Sub dial switch 6	Sub dial switch 7	set time for
OFF	OFF	OFF	OFF	3 coins (Factory setting)
ON	OFF	OFF	OFF	1 coin
OFF	ON	OFF	OFF	2 coins
ON	ON	OFF	OFF	3 coins
OFF	OFF	ON	OFF	4 coins
ON	OFF	ON	OFF	5 coins
OFF	ON	ON	OFF	6 coins
ON	ON	ON	OFF	7 coins
OFF	OFF	OFF	ON	8 coins
ON	OFF	OFF	ON	9 coins
OFF	ON	OFF	ON	10 coins
ON	ON	OFF	ON	11 coins
OFF	OFF	ON	ON	12 coins
ON	OFF	ON	ON	13 coins
OFF	ON	ON	ON	14 coins
ON	ON	ON	ON	15 coins

Sub dial switch 8 : ON Start standby music

OFF Close standby music

Sea World Diagram



1. Forward motor
2. coin meter
3. Reversing motor
4. brake
5. Walking light 1
6. Walking light 2
7. Walking light 3
8. Walking light 4
9. insert coins
10. Free button
11. sensor
12. Emergency stop button
13. sensor of safety belt
14. +12V
15. GND